

应急参考手册

SKP-NX 系列 标准电话







SAMSUNG

三星电子公司





外线呼叫

| 项 目 | 顺 序 (按动特定键以实现特定功能) |
|---------------|---|
| | <p>● 选择空闲外线</p> <p>(电话号码)</p> |
| | <p>● 选择特定外线</p> <p>[标准话机]</p> <p>(电话号码)</p> |
| | <p>● 在具体线组中选择空闲外线</p> <p>(电话号码)</p> |
| <p>应答外线呼叫</p> | |









呼叫处理

| 项 目 | 顺 序 (按动特定键以实现特定功能) | | | | | | | | | | | | | | | | | | | | | | | | |
|---------------|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|
| <p>设定会议电话</p> |  → H/F → <input type="text" value="4"/> <input type="text" value="6"/> → <table border="1" data-bbox="800 295 868 375"> <tr><td>1</td><td>2</td><td>3</td></tr> <tr><td>4</td><td>5</td><td>6</td></tr> <tr><td>7</td><td>8</td><td>9</td></tr> <tr><td>*</td><td>0</td><td>#</td></tr> </table> 分机号码/ 外线号码 <p>● 加入自己号码</p> <p>H/F</p> <p>● 从会议组释放</p> <p>H/F → <table border="1" data-bbox="700 502 767 582"> <tr><td>1</td><td>2</td><td>3</td></tr> <tr><td>4</td><td>5</td><td>6</td></tr> <tr><td>7</td><td>8</td><td>9</td></tr> <tr><td>*</td><td>0</td><td>#</td></tr> </table> 分机号码/ 外线号码</p> | 1 | 2 | 3 | 4 | 5 | 6 | 7 | 8 | 9 | * | 0 | # | 1 | 2 | 3 | 4 | 5 | 6 | 7 | 8 | 9 | * | 0 | # |
| 1 | 2 | 3 | | | | | | | | | | | | | | | | | | | | | | | |
| 4 | 5 | 6 | | | | | | | | | | | | | | | | | | | | | | | |
| 7 | 8 | 9 | | | | | | | | | | | | | | | | | | | | | | | |
| * | 0 | # | | | | | | | | | | | | | | | | | | | | | | | |
| 1 | 2 | 3 | | | | | | | | | | | | | | | | | | | | | | | |
| 4 | 5 | 6 | | | | | | | | | | | | | | | | | | | | | | | |
| 7 | 8 | 9 | | | | | | | | | | | | | | | | | | | | | | | |
| * | 0 | # | | | | | | | | | | | | | | | | | | | | | | | |
| <p>退出设定会议</p> |  → H/F → <table border="1" data-bbox="700 630 767 710"> <tr><td>1</td><td>2</td><td>3</td></tr> <tr><td>4</td><td>5</td><td>6</td></tr> <tr><td>7</td><td>8</td><td>9</td></tr> <tr><td>*</td><td>0</td><td>#</td></tr> </table> 您的分机号码 | 1 | 2 | 3 | 4 | 5 | 6 | 7 | 8 | 9 | * | 0 | # | | | | | | | | | | | | |
| 1 | 2 | 3 | | | | | | | | | | | | | | | | | | | | | | | |
| 4 | 5 | 6 | | | | | | | | | | | | | | | | | | | | | | | |
| 7 | 8 | 9 | | | | | | | | | | | | | | | | | | | | | | | |
| * | 0 | # | | | | | | | | | | | | | | | | | | | | | | | |
| <p>呼叫接收</p> |  ← <input type="text" value="1"/> <input type="text" value="0"/> → <table border="1" data-bbox="700 758 767 837"> <tr><td>1</td><td>2</td><td>3</td></tr> <tr><td>4</td><td>5</td><td>6</td></tr> <tr><td>7</td><td>8</td><td>9</td></tr> <tr><td>*</td><td>0</td><td>#</td></tr> </table> 分机号码/ 外线号码 <p>● 接收呼叫振铃</p>  ← <input type="text" value="*"/> | 1 | 2 | 3 | 4 | 5 | 6 | 7 | 8 | 9 | * | 0 | # | | | | | | | | | | | | |
| 1 | 2 | 3 | | | | | | | | | | | | | | | | | | | | | | | |
| 4 | 5 | 6 | | | | | | | | | | | | | | | | | | | | | | | |
| 7 | 8 | 9 | | | | | | | | | | | | | | | | | | | | | | | |
| * | 0 | # | | | | | | | | | | | | | | | | | | | | | | | |
| <p>回叫</p> | <p>H/F → <input type="text" value="4"/> <input type="text" value="4"/></p> | | | | | | | | | | | | | | | | | | | | | | | | |
| <p>发出紧急</p> |  → H/F → <input type="text" value="4"/> <input type="text" value="9"/> | | | | | | | | | | | | | | | | | | | | | | | | |
| <p>呼叫转移</p> | <p>H/F → <table border="1" data-bbox="548 1220 616 1300"> <tr><td>1</td><td>2</td><td>3</td></tr> <tr><td>4</td><td>5</td><td>6</td></tr> <tr><td>7</td><td>8</td><td>9</td></tr> <tr><td>*</td><td>0</td><td>#</td></tr> </table> 分机号码 → </p> | 1 | 2 | 3 | 4 | 5 | 6 | 7 | 8 | 9 | * | 0 | # | | | | | | | | | | | | |
| 1 | 2 | 3 | | | | | | | | | | | | | | | | | | | | | | | |
| 4 | 5 | 6 | | | | | | | | | | | | | | | | | | | | | | | |
| 7 | 8 | 9 | | | | | | | | | | | | | | | | | | | | | | | |
| * | 0 | # | | | | | | | | | | | | | | | | | | | | | | | |







拨号功能

| 项 目 | 顺 序 (按动特定键以实现特定功能) |
|--------------|---|
| 最后号码重拨 |  |
| 贮存号码重拨 |  |
| 快速拨号 (系统) |  → 速拨码 2 0 - 9 9 |
| 快速拨号 (个人) |  → 速拨码 2 0 - 9 9 |

寻呼及信息保留

| 项 目 | 顺 序 (按动特定键以实现特定功能) |
|--------|--|
| 寻呼 |  → 寻呼区号码 0 5 * →  |
| 指定号码寻呼 |  → * →  → TRSF/ALM → 5 6 |
| 指定号码应答 |  →  |
| 留言 | H/F → 4 1 →  |
| 回复留言 |  |

方便功能

| 项 目 | 顺 序 (按动特定键以实现特定功能) |
|------|---|
| 免打扰 | <p>● 设定DND</p>  <p>● 释放DND</p>  |
| 警报设定 |  |
| 呼叫转移 | <p>● 全部呼叫转移</p>  <p>● 遇忙呼叫转移</p>  <p>● 无应答呼叫转移</p>  |



CODE : GB68-70510A

Edition : 01 DN

July 1997

Printed In Korea